

















# DRIVO II

INTERACTIVE POWER METER MUIN

- CN 说明
- CZ INSTRUKCE
- DA INSTRUKTIONS
- DE ANLEITUNG
- EN INSTRUCTIONS
- ES INSTRUCCIONES
- FR MODE D'EMPLOI
- IT ISTRUZIONI
- JP 説明書
- KR 지침
- NL INSTRUCTIES
- PL INSTRUKCJE
- PT INSTRUÇÕES
- SK INŠTRUKCIE



**ELITE S.R.L.**  
VIA FORNACI, 4  
35014 FONTANIVA  
PADOVA - ITALY  
PHONE +39 049 594 0044  
E-MAIL: INFO@ELITE-IT.COM  
ELITE-IT.COM



